

151

FIG. 1 is a block diagram of a system for displaying a list of channels and their associated data. The system includes a display unit 10, a control unit 20, and a data source 30. The display unit 10 is connected to the control unit 20, which is connected to the data source 30. The display unit 10 displays a list of channels and their associated data. The control unit 20 controls the display unit 10 and the data source 30. The data source 30 provides data to the control unit 20.

26

CHANNEL - 213
NUMBER

Title - 214

Channel - 212
Logo

Start & End Times - 216

210

Summary... - 218

220a 220b 222b

Category

CC

AA

O

TVPG

●

HDTV

24

16

24

232

Channel 000's

230


00	01	02	03	04	05	06	07	08	09
10	11	12	13	14	15	16	17	18	19
20	21	22	23	24	25	26	27	28	29
30	31	32	33	34	35	36	37	38	39
40	41	42	43	44	45	46	47	48	49
50	51	52	53	54	55	56	57	58	59
60	61	62	63	64	65	66	67	68	69
70	71	72	73	74	75	76	77	78	
80	81	82	83		85	86	87	88	89
90			93	94	95	96	97	98	99

230

230

FIG 2

F1G3



Menu Preferences

Display Financial Programs

OFF

3.

Menu Settings


524

222

500

9156

Copyright © 2000 by Philips North America Consumer Electronics
All rights reserved. Philips, the Philips shield logo, and the Philips
"Double Diamond" logo are registered trademarks of Philips North America
Consumer Electronics. All other trademarks are the property of their respective
owners.



345-78 213 Swift Smart and Deadly-214

MSNBC-212 9:00 pm - 10:00 pm - 216

Logo

Test the limits of shark smarts with two New Zealand...

210 220 222 224 226 228 230 232 234 236 238 240 242 244 246 248 250 252 254 256 258 260 262 264 266 268 270 272 274 276 278 280 282 284 286 288 290 292 294 296 298 299

Sports 210 CC AA TVPG HDTV




FIG 8

343-213
 MSNBE MNT
 Logo
 Movies
 210
 218
 Comedy, Romance, Movie (1984) Tom Hanks, Daryl Hannah, Eugene ...
 216
 9:00 pm - 10:00 pm
 Splash
 214

Movies
 210
 218
 Comedy, Romance, Movie (1984) Tom Hanks, Daryl Hannah, Eugene ...
 216
 9:00 pm - 10:00 pm
 Splash
 214

Channel 300's

00	01	02	03	04	05	06	07	08	09
10	11	12	13	14	15	16	17	18	19
20	21	22	23	24	25	26	27	28	29
30	31	32	33	34	35				
40	41	42	43	44	45	46	47	48	49
50	51	52	53	54	55	56	57	58	59
60	61	62	63	64	65	66	67	68	69
70	71	72	73						
80	81	82	83		85	86	87	88	89
90			93	94	95	96	97	98	99

FIG 9